

Assembly Instructions Performance Accessory Bar

Part Numbers:


5200-3-500-24, 5200-3-500-48, 5200-3-500-72, 5200-3-500-96




Information Support Concepts 2384 Highway 287 N. Suite 208 Mansfield, TX 76063-9207

800-458-6255 U.S. Only Fax (817) 842-9099 Local (817) 842-9090

www.serverrackoptions.com








Slide both mounting brackets on both ends of the Accessory Bar.

Step 2:



Place channel nuts behind inside flanges of uprights. Install bolts through mounting bracket into channel nuts.

Step 3:



Adjust height of both brackets until the Accessory Bar is level. Use hex wrench to secure bolts.